

Automatic feeder

Model AFP6/AFP8

Pear

The automatic feeder, together with the peeler PL6/PL8, forms the complete automatic line for pears. The pears are loaded into a tank and from here they are singulated and transferred to an orientation station. In this station, the pears are orientated with the stalk down and placed in a hopper. In the final step, the pears are pushed from the funnels into the cups of the peeler. The electrical cabinet of the feeder is interfaced with the electrical cabinet of the connected peeler for synchronisation of the mechanisms.

The whole structure is positioned on a sliding carriage for easy access to the peeler during maintenance.





BRAND





















Automatic feeder

Model AFP6/AFP8

Pear



SPECIFICATIONS

CAPACITY

OPERATORS

DIMENSIONS (LXWXH)

WEIGHT

POWER

AIR PRESSURE / CONSUMPTION

WATER PRESSURE / CONSUMPTION

FRUIT SIZE

AFP6

60 pieces p/min

1800 x 1900 x 1900 mm

650 kg

1.4 kW

Ø 60 - 90 mm

AFP8

80 pieces p/min

2000 x 1900 x 1900 mm

850 kg 1.4 kW

Ø 60 - 90 mm















We have the expertise